

EXQUISITE INSTALLATION INSTRUCTIONS

creative
materials
corporation



Calacatta Viola



Botticino

Joint Spacing

For best results, it is recommended that the tiles are installed with minimum 1/16" joints to accommodate slight dimensional variances.

Pre-Installation

Conduct a dry lay on a flat substrate to make any necessary adjustments or modifications before installation.

Mortar

Use a premium high-performing latex modified thinset mortar with non-sag characteristics. Do not use Organic Type 1 adhesives.

Proper Bedding

Pack and fill the mortar to 100% coverage as to not leave any voids or hollow spots. Due to the tile's unique concave backing, 100% mortar coverage is essential and required. When packing the backside of the tile, utilize the standard back-buttering technique with the flat side of the trowel. Once fully packed, the filled mortar shall be flat, smooth and flush with the edges of the tile.

Grout

We recommend unsanded cementitious grouts or single component modified grouts.

Please contact our Quality Assurance & Technical team at info@creativematerialscorp.com if you have any questions.