

# TERRAFORM INSTALLATION INSTRUCTIONS

creative  
materials  
corporation



## Joint Spacing

For best results, it is recommended that the tiles are installed with minimum 1/16" joints to accommodate slight dimensional variances.

## Pre-Installation

Conduct a dry lay on a flat substrate to make any necessary adjustments or modifications before installation.

## Mortar

Use a premium high-performing latex modified thinset mortar with non-sag characteristics. Do not use Organic Type 1 adhesives.

## Proper Bedding

Pack and fill the mortar to 100% coverage as to not leave any voids or hollow spots. Due to the tile's unique concave backing, 100% mortar coverage is essential and required. When packing the backside of the tile, utilize the standard back-buttering technique with the flat side of the trowel. Once fully packed, the filled mortar shall be flat, smooth and flush with the edges of the tile.

**NOTE:** This applies to all profiles with the exception of Plateau and Stacked. Please contact our Quality Assurance & Technical team at [info@creativematerialscorp.com](mailto:info@creativematerialscorp.com) so we can understand the scope of the project for specific installation instructions.

## Grout

We recommend unsanded cementitious grouts or single component modified grouts.